





# HP Pavilion home PC




© 2004 Hewlett-Packard Development Company, L.P.  
Printed in  
www.hp.com






5 9 9 0 - 8 0 9 1



## 1 Keyboard and Mouse 鍵盤和滑鼠





## Wireless option Please refer to the setup instructions located in your mouse/receiver box.



無線選購裝置  
請參閱滑鼠/接收器盒內的安裝指示。




## 2 Monitor 顯示器 請參閱顯示器隨附的安裝指示。




## 3 Speakers 喇叭 請參閱喇叭隨附的安裝指示。




## 4 Power Connection 電源連接




## 5 Modem / LAN 數據機 / LAN



OR  
或




## 6 Power On 電源開啓






**NOTE:** Your components and connection locations may vary by model.  
注意事項：您的組件與連接位置可能會因型號而異。



- A — Optical drives
  - B — Optical drive Eject buttons
  - C — Floppy drive
  - D — Card reader
  - E — Headphones
  - F — Microphone
  - G — USB 2.0 ports
  - H — FireWire® (IEEE 1394) port
  - I — Door
  - J — On button with Indicator
  - K — Hard drive Activity light
- A — 光碟機
  - B — 光碟機「退出」鈕
  - C — 軟碟機
  - D — 讀卡機
  - E — 耳機
  - F — 麥克風
  - G — USB 2.0 連接埠
  - H — FireWire® (IEEE 1394) 連接埠
  - I — 門
  - J — 「主機開關按鈕」及其指示燈
  - K — 硬碟作業指示燈



- A — Power LED
  - B — Voltage selector
  - C — Power Cord connector
  - D — PS/2 Mouse connector
  - E — PS/2 Keyboard connector
  - F — Serial port
  - G — Parallel port
  - H — VGA Monitor port
  - I — 4 USB 2.0 ports
  - J — LAN (Ethernet)
  - K — Microphone connector
  - L — Audio Line Out
  - M — Audio Line In
  - N — Modem (Line In RJ-11)
- Select models only:**
- O — Digital Audio In
  - P — Digital Audio Out
  - Q — FireWire® (IEEE 1394) port
  - R — Side speaker port
  - S — Rear speaker port
  - T — Center speaker/subwoofer port
- A — 電源 LED
  - B — 電壓選擇開關
  - C — 電源線插孔
  - D — PS/2 滑鼠接頭
  - E — PS/2 鍵盤接頭
  - F — 序列埠
  - G — 並列埠
  - H — VGA 顯示器連接埠
  - I — 4 個 USB 2.0 連接埠
  - J — LAN (乙太網路)
  - K — 麥克風插孔
  - L — 音訊音源輸出孔
  - M — 音訊音源輸入孔
  - N — 數據機 (線路輸入 RJ-11)
- 僅限於部分型號：
- O — 數位音訊音源輸入孔
  - P — 數位音訊音源輸出孔
  - Q — FireWire® (IEEE 1394) 連接埠
  - R — 側置喇叭連接埠
  - S — 後置喇叭連接埠
  - T — 中置喇叭/重低音喇叭連接埠